



USER MANUAL

200Watts
Dual 18650 in series



POWERED BY
EVOLV | DNA 250C

1. INTRODUCTION
2. STANDARD PACKAGE
3. MAIN FEATURES
4. EVOLV DNA 250C
5. ESCRIBE
6. DISPLAY OF DNA 250C
7. ERROR MESSAGES
8. PUFF REPLAY
9. CHARGING AND USB ON-THE-GO
10. PRECAUTIONS
11. WARRANTY

1 INTRODUCTION

The Paranormal DNA 250C is the highly advanced edition of the Paranormal series, boosting in power with the integration of Evolv's latest DNA 250C Color Chipset while maintaining the beloved chassis design and luxury materials.

The Paranormal DNA 250C utilizes Evolv's most advanced DNA 250C board with down-throttled power, featuring an incredible 98% output efficiency rating, tremendous range from 1 to 200 watts, new puff replay feature to maintain preferred puffs, and couple with USB On-The-Go feature for power sharing.

2 STANDARD PACKAGE

- 1 x Paranormal DNA250C Device
- 1 x Paranormal User Manual
- 1 x Customized Side Panels
- 1 x USB Connecting Cable
- 1x USB On-The-Go Adaptor

3 MAIN FEATURES

- * Powered By Evolv Firmware Upgradable DNA 250C Board
- * Dual 18650 Cells Setup For Long-Lasting Power
- * Theme Designer Software/Customizable User Interface
- * Temperature Limit: 200°F-600°F
- * Output Power: 1Watt-200Watts
- * Puff Replay
- * USB On-The-Go Charger
- * Body Material: Die Cast Zinc Alloy

4 EVOLV DNA 250C

The DNA 250C is a power regulated digital switch-mode DC-DC converter for personal vaporizers. It features Evolv's patented Wattage Control, Temperature Protection, Puff Replay, Preheat, full color TFT screen, On-The-Go USB, Reverse Polarity Protection, an onboard programmable multicolor LED, waterproof onboard buttons, and a real-time clock. Evolv's Escribe software and Theme Designer software can be used to fully customize all aspects of the interface and monitor the user experience. The DNA 250C runs on two lithium ion batteries, and features battery monitoring and an integrated 2A charger.

5 ESCRIBE

Escribe is a software package used to configure, monitor and modify the operation of your DNA 250C. It installs on a Windows PC and connects to your DNA 250C using the USB port. Escribe has a separate manual and tutorials which can be found on Evolv's site.

<http://www.evolvapor.com/>
<http://www.evolvapor.com/manuals/EScribeManual.pdf>

6 DISPLAY OF DNA 250C

To wake the device from power off state, tap the Fire button. To generate vapor, press the Fire button. To change the wattage setting for more or less vapor, click or hold the Up and Down buttons.

Display

The DNA 250C has a full color 80 x 160 pixel TFT screen



7 ERROR MESSAGES

The DNA 250C will indicate a variety of error states.

Check Atomizer: The DNA does not detect an atomizer, the atomizer has shorted out, or the atomizer resistance is incorrect for the power setting.

Weak Battery: The battery is deeply discharged and needs to be charged, or is damaged. If this happens, the DNA 250C will not fire the atomizer. The Check Battery message will continue to display for a few seconds after attempting to fire the device. User should remove and replace the battery.

Shorted: The atomizer or wiring are short circuited.

8 PUFF REPLAY

Puff Replay is a new feature on the DNA 250C that allows the user to save and play back puffs. The use of a temperature sensitive material is required such as Nickel, Stainless, Titanium, or other material that increases in resistance when heated. Puff Replay works in either temperature protection or wattage control modes and will also prevent dry hits when used with wattage control.

To use Puff Replay set the device to the desired power level and operate it normally. Once a satisfying puff is achieved, activate Puff Replay to replay the last puff on all subsequent uses. Puff length is not a factor and the user will not be limited to the length of the previous puff. Disable Puff Replay to resume normal operation or find a new puff to save. If Puff Replay cannot be enabled the coil is not compatible.

9 CHARGING AND USB ON-THE-GO

Charging the Batteries

Internal Charging: The DNA 250C has a built in 2A USB charger. It automatically detects the type of USB power supply it is connected to, so it can be plugged into standard PC USB ports or higher power chargers. The max charge current is based on the cell capacity as programmed in Escribe.

External charging (Recommended): Use batteries from device. Follow charging instructions with using charger.

USB On-The-Go

The DNA 250C supports USB On-The-Go. An OTG adaptor may be plugged into the Micro USB port on the device to charge any other device capable of charging via USB. Charging starts and stops automatically and OTG charging will not over-drain the DNA 250C.

10 PRECAUTIONS

Please read the following safety recommendations before using this device.

1. This device is intended for users over the age of 18, and not by minors, women who are pregnant or breast feeding, or people with or at risk of heart disease, high blood pressure, hypertension, diabetes, or taking medicine for depression or asthma.
2. This products is sold purely for recreational purpose, it is not a smoking cessation product and has not been tested as such.
3. Please ensure this product is kept away from extreme high and low temperatures and moist environment while in use or stored.

11 WARRANTY

LOST VAPE Paranormal DNA 250C are covered by a 6 months limited warranty from the date of your retail purchase. The warranty will be void if there are any signs that the product has been physically damaged, dropped or abused in any way.

For warranty issues, please contact LOST VAPE official retailers and distributors for their warranty and return policy. LOST VAPE's warranty does not apply to products purchased through unauthorized vendors.

12 PATENT PENDING

Designed and Manufactured by LOST VAPE LTD.
Visit us at: www.lostvape.com
Follow us on: Facebook.com/LostVapeLtd
Instagram: LOST_VAPE
Copyright © 2018 LOST VAPE. All Rights Reserved



LOST VAPE®




MADE IN CHINA



PARANORMAL
—DNA250C—

USER MANUAL

200Watts
Dual 18650 in series



PARANORMAL
—DNA250C—

POWERED BY
EVOLV | DNA 250C

1. INTRODUCTION
2. STANDARD PACKAGE
3. MAIN FEATURES
4. EVOLV DNA 250C
5. ESCRIBE
6. DISPLAY OF DNA 250C
7. ERROR MESSAGES
8. PUFF REPLAY
9. CHARGING AND USB ON-THE-GO
10. PRECAUTIONS
11. WARRANTY

1 INTRODUCTION

The Paranormal DNA 250C is the highly advanced edition of the Paranormal series, boosting in power with the integration of Evolv's latest DNA 250C Color Chipset while maintaining the beloved chassis design and luxury materials.

The Paranormal DNA 250C utilizes Evolv's most advanced DNA 250C board with down-throttled power, featuring an incredible 98% output efficiency rating, tremendous range from 1 to 200 watts, new puff replay feature to maintain preferred puffs, and couple with USB On-The-Go feature for power sharing.

2 STANDARD PACKAGE

- 1 x Paranormal DNA250C Device
- 1 x Paranormal User Manual
- 1 x Customized Side Panels
- 1 x USB Connecting Cable
- 1x USB On-The-Go Adaptor

3 MAIN FEATURES

- * Powered By Evolv Firmware Upgradable DNA 250C Board
- * Dual 18650 Cells Setup For Long-Lasting Power
- * Theme Designer Software/Customizable User Interface
- * Temperature Limit: 200°F-600°F
- * Output Power: 1Watt-200Watts
- * Puff Replay
- * USB On-The-Go Charger
- * Body Material: Die Cast Zinc Alloy

4 EVOLV DNA 250C

The DNA 250C is a power regulated digital switch-mode DC-DC converter for personal vaporizers. It features Evolv's patented Wattage Control, Temperature Protection, Puff Replay, Preheat, full color TFT screen, On-The-Go USB, Reverse Polarity Protection, an onboard programmable multicolor LED, waterproof onboard buttons, and a real-time clock. Evolv's Escribe software and Theme Designer software can be used to fully customize all aspects of the interface and monitor the user experience. The DNA 250C runs on two lithium ion batteries, and features battery monitoring and an integrated 2A charger.

5 ESCRIBE

Escribe is a software package used to configure, monitor and modify the operation of your DNA 250C. It installs on a Windows PC and connects to your DNA 250C using the USB port. Escribe has a separate manual and tutorials which can be found on Evolv's site.

<http://www.evolvapor.com/>
<http://www.evolvapor.com/manuals/EScribeManual.pdf>

6 DISPLAY OF DNA 250C

To wake the device from power off state, tap the Fire button. To generate vapor, press the Fire button. To change the wattage setting for more or less vapor, click or hold the Up and Down buttons.



The DNA 250C has a full color 80 x 160 pixel TFT screen

7 ERROR MESSAGES

The DNA 250C will indicate a variety of error states.

Check Atomizer: The DNA does not detect an atomizer, the atomizer has shorted out, or the atomizer resistance is incorrect for the power setting.

Weak Battery: The battery is deeply discharged and needs to be charged, or is damaged. If this happens, the DNA 250C will not fire the atomizer. The Check Battery message will continue to display for a few seconds after attempting to fire the device. User should remove and replace the battery.

Shorted: The atomizer or wiring are short circuited.

8 PUFF REPLAY

Puff Replay is a new feature on the DNA 250C that allows the user to save and play back puffs. The use of a temperature sensitive material is required such as Nickel, Stainless, Titanium, or other material that increases in resistance when heated. Puff Replay works in either temperature protection or wattage control modes and will also prevent dry hits when used with wattage control.

To use Puff Replay set the device to the desired power level and operate it normally. Once a subsequent puff is achieved, activate Puff Replay to replay the last puff on all subsequent uses. Puff length is not a factor and the user will not be limited to the length of the previous puff. Disable Puff Replay to resume normal operation or find a new puff to save. If Puff Replay cannot be enabled the coil is not compatible.

9 CHARGING AND USB ON-THE-GO

Charging the Batteries

Internal charging: The DNA 250C has a built in 2A USB charger. It automatically detects the type of USB power supply it is connected to, so it can be plugged into standard PC USB ports or higher power chargers. The max charge current is based on the cell capacity as programmed in Escribe.

External charging (Recommended): Use batteries from device. Follow charging instructions with using charger.

USB On-The-Go

The DNA 250C supports USB On-The-Go. An OTG adaptor may be plugged into the Micro USB port on the device to charge any other device capable of charging via USB. Charging starts and stops automatically and OTG charging will not over-drain the DNA 250C.

10 PRECAUTIONS

Please read the following safety recommendations before using this device.

1. This device is intended for users over the age of 18, and not by minors, women who are pregnant or breast feeding, or people with or at risk of heart disease, high blood pressure, hypertension, diabetes, or taking medicine for depression or asthma.
2. This products is sold purely for recreational purpose, it is not a smoking cessation product and has not been tested as such.
3. Please ensure this product is kept away from extreme high and low temperatures and moist environment while in use or stored.

11 WARRANTY

LOST VAPE Paranormal DNA 250C are covered by a 6 months limited warranty from the date of your retail purchase. The warranty will be void if there are any signs that the product has been physically damaged, dropped or abused in any way.

For warranty issues, please contact LOST VAPE official retailers and distributors for their warranty and return policy. LOST VAPE's warranty does not apply to products purchased through unauthorized vendors.

Patent Pending
Designed and Manufactured by LOST VAPE LTD.
Visit us at: www.lostvape.com
Follow us on: Facebook.com/LostVapeLtd
Instagram: LOST_VAPE
Copyright © 2018 LOST VAPE. All Rights Reserved



LOST VAPE®

