



DRONE

— B F —



USER MANUAL

Dual 18650 in Series



EVOLV | DNA166

1. INTRODUCTION

7. MODES

2. STANDARD PACKAGE

8. PROFILE

3. MAIN FEATURES

9. ERROR MESSGAES

4. EVOLV DNA 250

10. INSTALLING AND CHARGING

5. ESCRIBE

11. PRECAUTIONS

6. BASIC OPERATION OF DNA 250

12. WARRANTY

1. INTRODUCTION

The Drone BF mod by Lost Vape is a 166 watt dual 18650s in series mod that features with a customized 11 ml juice bottle. Utilizing the DNA 250 board from Evolv, the Drone 166W is constructed from die cast zinc alloy, a durable and lightweight blend. Basically, the Drone 166W is designed to fulfill the long-lasting needs for a powerful and comfortable squonker.

The front of the Drone 166W features a high-definition OLED screen, the activation button, adjustment buttons and USB charging port. The HD OLED screen clearly displays an array of important information for the user like the current output wattage, temperature of the coil, resistance of atomizer being used and remaining battery life.

The magnetic cover for battery housing makes effortless to switch batteries and squonk e-juice bottle. It is the divided design of the battery sled and juice bottle sled that sports the Drone 166 W. This design was made to ensure the safety of squonking.

The 510 connector is made from solid stainless steel for long life usage, and the spring loaded positive pin is nickel plated brass for accurate temp control and resistance readings.

In order to satisfy and spare vapers' needs and time, Lost Vape Drone 166W provides preset profiles in Nickel (Ni200), Titanium (Ti) and Stainless Steel (SS) coil builds for ready to go.

2. STANDARD PACKAGE

- 1 x Drone 166W BF Box Mod
- 1 x USB Charging Cable
- 1 x 11ML Squonk E-juice Bottle
- 1 x Drone 166W User Manual

510 Atomizer Connector

Removable Back Door

11 ML Squonk E-Juice Bottle

USB Port (Charging & Update Firmware)

Fire Button

Up Button
Down Button



3. MAIN FEATURES

- * Powered by Evolv DNA250 temperature protection board
- * With Evolv's Escribe software, dial in your perfect vape with over 93 options
- * Dual 18650 batteries in series
- * Firmware upgradeable
- * Die cast zinc alloy body
- * Temperature Limit: 200°F - 600°F
- * Output Power: 1Watt - 166Watts
- * Custom made built-in 11.0 ML squonk e-juice bottle

- * Stainless steel 510 atomizer connector
- * Compatible with all regular atomizers
- * Spring loaded stainless steel positive pin
- * On board reverse polarity protections
- * Requires a bottom feed atomizer to work properly (not included)
- * Integrated 2Amp micro-USB on-board balanced charger (cord included)
- * Cell-by-cell monitoring
- * Pass-thru charging functionality
- * Dimensions: 94.5mm*50mm*41mm

4. EVOLV DNA 250

The DNA 250 is a power regulated digital switch-mode DC-DC converter for personal vaporizers. It features Evolv's patented Wattage Control, Temperature Protection, Preheat, OLED Screen, and waterproof onboard buttons. The USB port and Evolv's EScribe software can be used to customize or monitor the user experience. The DNA 250 features cell-by-cell battery monitoring and integrated 2A balance charger.


Specifications	Minimum	Typical	Max
Output Power	1 Watt		250 Watts
Output Voltage	0.5 Volt		9.3 Volts
Output Current, continuous			55.0 Amps

Output Current, instantaneous peak			60.0 Amps
Atomizer Resistance, temperature sensing wire, cold	See Graph	0.10 Ohm	See Graph
Atomizer Resistance, kanthal wire	See Graph	0.20 Ohm	See Graph
Temperature Limit	200°F	450°F	600°F
Input Voltage	9.0 Volts	11.1 Volts	12.6 Volts
Input Current	0.5 Amps	9.0 Amps	28.0 Amps
Screen On Current	21mA		
Quiescent Current	3.5mA		
Power Down Current	25uA		
Efficiency	97%		
Weight	15g		
Footprint	71" x 2.80"		18mm x 71mm
Thickness	0.32"		
Screen size	0.91" OLED		


Output Power

The following graphs show the output power range of the DNA 250 as a function of the coil resistance.


DNA 250 Kanthal Power




DNA 250 Kanthal Power Extended



DNA 250 Nickel Power



DNA 250 Nickel Power Extended



Temperature Protection

The DNA 250 directly measures and limits the temperature of the heating coil during operation. By preventing the coil from becoming too hot regardless of fluid, wicking or airflow, a variety of undesirable situations can be prevented. For example, appropriate temperature settings will prevent the wicking material from charring, which compromises taste and introduces unintended chemicals into the vapor. Appropriate temperature settings will also reduce the breakdown of flavoring and base liquid components, which could impact taste or safety.

Evolv's Temperature Protection Technology requires a heating coil made from Nickel 200 alloy or other materials with a well-defined temperature coefficient of resistance, rather than Nickel Chromium or Kanthal alloys. If the temperature

reaches the maximum value, the wattage applied to the atomizer coil is reduced to prevent overheating. Please note that the temperature reading is the average temperature of the atomizer coil, and care should be taken to construct the heating coil so that the temperature is uniform, without hot or cold spots.

Because wattage, not temperature controls vapor volume, large vapor volumes can be produced without unnecessarily high temperatures. Temperature Protection is most helpful if the atomizer begins to dry out, the user pauses during a puff, the beginning or end of the puff, or if the wattage setting is inappropriate for the attached atomizer.

In normal operation, when the device is not firing the maximum temperature setting is displayed on the screen. When the device is firing, the actual average temperature of the coil is displayed on the screen.

By default, the Temperature Protection setting is 450° Fahrenheit. To change the limit

- 1) Lock the device by pressing the Fire button five times.
- 2) Hold down the UP and DOWN adjust buttons for two seconds.
- 3) After two seconds, the maximum temperature will be displayed, and the UP and DOWN buttons should be released.
- 4) Use the UP and DOWN buttons to adjust the maximum temperature
- 5) When the display shows the desired maximum temperature, press the Fire button to exit temperature adjust mode.

The maximum temperature is adjustable between 200° Fahrenheit and 600° Fahrenheit. To disable the temperature protection entirely, adjust the limit up to 600 degrees, then press the UP button one additional time. The temperature limit will read OFF.

To switch to Celsius temperature, adjust temperature down to 200° Fahrenheit, then press the DOWN one button one additional time. The temperature will switch to reading and adjusting in Celsius.

Preheat

When the DNA 250 is used with a temperature sensing atomizer, an additional feature called Preheat is activated. No vapor is produced when the temperature is below the boiling point of the liquid. Preheat applies extra power until the heating coil is up to operating temperature to shorten the delay between pressing the fire button and generating vapor. Because preheat is temperature based, it will not overheat or burn the vapor.

Attaching a New Atomizer

The DNA 250 uses the resistance of the atomizer to calculate the temperature of the heating coil. It continually looks to see whether a new or changed atomizer has been connected. If you are using temperature protection, be careful to only attach new atomizers that have cooled to room temperature. If a new atomizer is attached to the DNA 250 before it has cooled down, the temperature may read and protect incorrectly until the new atomizer cools.

When you connect a new atomizer or disconnect and reconnect your existing atomizer, the DNA 250 will prompt you to confirm this change. When you fire the first time, before activating the DNA 250 will prompt "New Coil? UP YES/DOWN NO". When you see this prompt, if you have attached a new atomizer, press the UP button. If you have disconnected and reconnected the same atomizer, press the DOWN button.

5. *Escribe*

Escribe is a software package used to configure, monitor and modify the operation of your DNA 250. It installs on a Windows PC and connects to your DNA 250 using the USB port. Escribe has a separate manual and tutorials which can be found on Evolv's site. Users must go to the Escribe and update the latest firmware before using the device.

<http://www.evolvapor.com/>

<http://www.evolvapor.com/manuals/EScribeManual.pdf>

6. BASIC OPERATION OF DNA250

To wake the device from power off state, tap the Fire button. To generate vapor, press the Fire button. To change the wattage setting for more or less vapor, click or hold the Up and Down buttons.

Display

The DNA 250 has a small .91" diagonal white OLED screen.



Alternate display items		
Battery Charge	Output Current	Average Output Power of the most recent puff
Battery Pack Voltage	USB Voltage	Average Temperature of the most recent puff
Cell 1 Voltage	USB Current	Total Energy of the most recent puff
Cell 2 Voltage	Board Temperature	Duration of the most recent puff
Cell 3 Voltage	Room Temperature	Puff Count
Profile Name	Material Name	

Watt setting: The power level currently set on the DNA 250.

Battery indicator: The current state of charge of the battery.

Temperature display: When not firing, the maximum heating coil temperature setting. While firing, the actual temperature of the heating coil is displayed.

Volts display: The output voltage being supplied to the atomizer.

Ohms display: The resistance of the atomizer attached to the device. When using a temperature sensing coil, this is the normalized resistance of the coil at 70°F

7. Modes

Locked mode: Pressing the fire button five times with less than .7 seconds between presses will cause the device to enter Locked mode. In Locked mode, the device will not fire and the output power will not adjust accidentally. While in Locked mode, the screen will be off, except that pressing a button will show “Locked, Click 5X”. To exit Locked mode, press the fire button 5 times.

Stealth mode: While locked, holding the fire and down buttons simultaneously for five seconds will switch to stealth mode. In this mode the display is off. It will still show error and lock messages. To switch back to normal display mode, hold down the fire and down buttons simultaneously for 5 seconds. This setting is stored to internal flash memory, and remains if power is removed.

Power Locked mode: Holding down both the up and down buttons for two seconds will place the device in Power Locked mode. In this mode, the mod will operate normally, but you will not be able to change the power setting. This mode prevents accidental power level changes due to the buttons being pressed while in a pocket. To exit Power Locked mode, hold the up and down buttons for two seconds.

Resistance lock: The DNA 250 relies on the cold resistance of the atomizer to measure temperature accurately. If the connection is not stable or if you find the measured resistance drifts with time, it may be desirable to lock the atomizer resistance. To do so, while locked hold both the Fire and Up buttons for two seconds to enter Resistance.

Lock mode: In this mode, the DNA 250 will use the present atomizer cold resistance without refinement until the atomizer is disconnected or the resistance lock is disabled. A lock symbol will replace the ohm symbol on the display. To disable resistance lock, repeat the procedure to lock it.

Max Temperature Adjust: From Locked Mode, holding down both the up and down buttons for two seconds will place the device in Max Temperature Adjust mode. Once this mode is entered, the max temperature will be displayed. The up and down buttons are used to adjust the max temperature. To save the new temperature setting and exit, press the Fire button.

8. Profiles

The DNA 250 allows you to save and select between eight groups of output settings. Each group of output settings is called a Profile. To switch between profiles, put the DNA 250 into Power Locked mode by pressing and holding both the up and down buttons for two seconds. From power locked mode, to cycle between profiles, double click the Up or Down button. To select the displayed profile, press the fire button.

Each profile contains an output power setting and a maximum temperature setting. These can be adjusted on the device, and will be saved when a different profile is selected. Additionally, the resistance lock setting and value for each

atomizer is saved in the profile, which can alleviate temperature inaccuracies stemming from attaching atomizers before they have completely cooled. Many more output settings, including the coil material and preheat settings can be adjusted on a per-profile basis using the Escribe PC software.

Evolv recommends setting up one profile for each atomizer that you regularly use with the DNA 250. It is much faster to switch profiles than it is to set up the settings for the atomizer again.

9. Error Messages

The DNA 250 will indicate a variety of error states.

Check Atomizer: The DNA does not detect an atomizer, the atomizer has shorted out, or the atomizer resistance is incorrect for the power setting.

Shorted: The atomizer or wiring are short circuited.

Weak Battery: The battery needs to be charged, or a higher rate battery needs to be used. If this happens, the DNA 250 will continue to fire the atomizer, but will not be able to provide the desired wattage. The Weak Battery message will continue to flash for a few seconds after the end of puff.

Temperature Protected: The heating coil reached the maximum allowed temperature during the puff. If this happens, the DNA 250 will continue to fire, but will not be able to provide the desired wattage.

Ohms Too High: The resistance of the atomizer coil is too high for the current wattage setting. If this happens, the DNA 250 will continue to fire, but will not be able to provide the desired wattage. The Ohms Too High message will continue to flash for a few seconds after the end of puff.

Ohms Too Low: The resistance of the atomizer coil is too low for the current wattage setting. If this happens, the DNA250 will continue to fire, but will not be able to provide the desired wattage. The Ohms Too Low message will continue to flash for a few seconds after the end of puff.

Too Hot: The DNA 250 has onboard temperature sensing. It will shut down and display this message if the internal board temperature becomes excessive.

Auto power down: The screen will be at full brightness while firing. After 10 seconds with no button presses, the screen will dim. 30 seconds after the last button press, the screen will fade out and the device will go into sleep mode. To wake the device, press the fire button.

10. INSTALLING AND CHARGING

Installing Batteries and E-juice Bottle

When using the Drone 166W make sure to use married batteries. Meaning that the 2 cells are the exact same. NEVER use different brand, mAh, or age batteries.

When getting the Drone DNA250 you should use a set of 2 same batteries to be use only with the Drone 166W. You do not want to break up the set and use one or more of the batteries from the set in another device.

Install all two 18650 batteries according to the indicator inside the battery bay. Fill up the e-juice bottle, slide it into the squonking spot, and close the battery door.

Charging the Batteries

You have 2 options to charge your Drone DNA 166. You can either remove your 18650 batteries from the device and charge them via an external charger, or you can use the on-board charging option. It is best to remove them from the device and charge them via the external charger. This option will also be a faster method of charging.

External charging:

Remove batteries from device.

Follow charging instructions with using charger.

Internal charging:

When the battery level display indicates that the battery needs charging, plug one end of the supplied USB charging cable into your device.

Plug the other end of the charging cable into a USB power source (a computer usb port or usb wall plug).

Leave the device plugged in until the battery indicator displays fully charged.

Once the battery is fully charged unplug the USB cable from the device. (Never leave a battery charging unattended)

While charging your device with the USB cable you can still use your Drone DNA250.

11. PRECAUTIONS

Please read the following safety recommendations before using this device.

1. This device is intended for users over the age of 18, and not by minors, women who are pregnant or breast feeding, or people with or at risk of heart disease, high blood pressure, hypertension, diabetes, or taking medicine for depression or asthma.
2. This products is sold purely for recreational purpose, it is not a smoking cessation product and has not been tested as such.
3. Please ensure this product is kept away from extreme high and low temperatures and moist environment while in use or stored.
4. The manufacturer is not responsible for any damage or personal injury caused by inappropriate, incorrect or irresponsible use of the device. Use of any illegal or prohibited products with this device will void the warranty.

5. Do not over-tighten the atomizer onto the 510 connector, the atomizer should be snug, not tight. over-tightening may cause damage to the threading and the delrin insulator.
6. This is a high end and powerful device capable of providing a high voltage to the atomizer. We recommend only using the dual 18650 batteries in proper manner.
7. Due care and attention must be followed when using this mod. This is for experienced vapers with extensive knowledge of how electronic devices work along with access to the appropriate safety tools. Please ensure proper precautions are taken when using these devices as to not cause damage and/or harm to the atomizer, device, or yourself. Use at your own risk.

8. Battery safety is very important. If you remove the battery from the device, please store it in a dry place, at room temperature, and away from direct sunlight. The batteries should never be left unattended while charging. Please take extra care when you removing/replacing the battery. Always dispose of batteries in a safe manner, into a designated containers for battery recycling.

12. WARRANTY

LOST VAPE Drone DNA 166 are covered by a 6 months limited warranty from the date of your retail purchase. The warranty will be void if there are any signs that the product has been physically damaged, dropped or abused in any way.

For warranty issues, please contact LOST VAPE official retailers and distributors for their warranty and return policy. LOST VAPE's warranty does not apply to products purchased through unauthorized vendors.

Undefeated quality - Precise manufacturing

Patent Pending

Designed and Manufactured by SHENZHEN LOST VAPE LTD.

Visit us at: www.lostvape.com

Follow us on: [Facebook.com/LostVapeLtd](https://www.facebook.com/LostVapeLtd)

Instagram: [LOST_VAPE](https://www.instagram.com/LOST_VAPE)

Copyright © 2016 LOST VAPE. All Rights Reserved



LOST VAPE[®]



MADE IN CHINA